Philips Avance Collection
Masher accessory

Accessory for HR164x & HR167x

HR1965/90

Prepare a large variety of homemade food

Masher accessory, to mash potatoes and more

With the masher acessory for the Philips hand blender you can mash potatoes silky smooth. Also other vegetables can be mashed or pureed.

High performance Avance Hand Blender accessory
- High performance Avance Masher Accessory

Well suited for many models
- One click assembling to Avance SpeedTouch Hand Blender
- Fits Philips handblender models: HR164x & HR167x

Easy cleaning
- Dishwasher safe Philips Avance accessory

PHILIPS

Masher accessory
Accessory for HR164x & HR167x

HR1965/90

Specifications

Accessories
• Potato masher

General specifications
• Dishwasher safe

Highlights

Philips Avance masher Accessor

High performance Avance Masher Accessory

Easy assembly

Fits the Philips Avance SpeedTouch Hand Blender HR164x and HR167x with one click.

Fits models: HR164x & HR167x

Fits the following Philips Avance SpeedTouch Handblender models: HR164x and HR167x

Dishwasher safe

The Philips accessory can be cleaned easily in a dishwasher.

Issue date 2014-08-08

Version: 2.0.1

© 2014 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

www.philips.com